


## Follow below steps to make a full test of Barcode reader.

- 1. Make sure you have a Motorola or Symbol barcode reader compatible with VisitLog system. If you have any questions, contact support at <a href="mailto:support@riwsoftware.com">support@riwsoftware.com</a>
- 2. Keep the barcode reader unplugged
- 3. Go to "Local settings" under "Administrations":



- 4. Install drivers by click the button named: "Install Drivers". (Be sure it's not removing already installed drivers at the first guide form.)
- 5. Start the scanner application (tray application) by click the button named: "Restart". De red icon should be green when its active.
- 6. Put the USB cable from barcode reader into pc
- 7. Test the barcode reader mode (If fail go to d, else continue to 8):
  - a. Set mouse pointer to an area possible to write text, ex: Notepad, word etc
  - b. Read a barcode from any box or device or paper
  - c. If the barcode give a text in the text area, the barcode reader is not programed for serial reading (Test failed). It has to be reprogramed by next task.
  - d. Reprogram from Keyboard input (by default) to serial input. Only if above test was failed. Use below barcode. Read it with scanner and the scanner is reprogrammed.



- 8. Now test to print a badge from visitlog and scan the barcode at the badge with the scanner.
- 9. The visitor should be logged in or out. Message should be seen at the screen.
- 10. Ready! (If still any problems, please contact support at: <a href="mailto:suppot@riwsoftware.com">suppot@riwsoftware.com</a>)